




Quickstart





VC 4 Cordless myHome
VC 4 Cordless Premium myHome


A 


1 


B 


1 


2 


3 


C 


1A 


1B 


2 


3 


D 


1 


1A 


1B 


2 


E 


1 


2 

3 

F 

1A 

2 

3 

1B 