

# OUTSIDE

210 mm

## Buttons robot

-  **On/Off** Press for start or pause  
Press (5 sec) for turn on/off  
Press together with Home (5 sec)  
for WLAN connection
-  **Home** Press to send robot to station  
Press together with On/Off (5 sec)  
for WLAN connection
-  **Switch mode** Press to switch cleaning mode:  
dry cleaning or wet & dry cleaning



## Lights robot

- Device boot/  
Firmware update** LED On/Off & Home: white breathing  
LED stripe: white breathing
- Network connection** LED On/Off & Home: blue breathing  
LED stripe: off
- Robot standby** LED On/Off & Home: off  
LED stripe: off
- Robot charging** LED On/Off & Home: green breathing  
LED stripe: off
- Robot cleaning** LED On/Off & Home: yellow (dry cleaning)  
or blue (wet & dry cleaning)  
LED stripe: yellow (dry cleaning)  
or blue (wet & dry cleaning)
- Error** LED On/Off & Home: red blinking  
LED stripe: red blinking

## Kärcher Indoor Robots App



### Scan for details



[www.kaercher.com/int/home-garden/robot-vacuums-and-mops.html](http://www.kaercher.com/int/home-garden/robot-vacuums-and-mops.html)

### Operating Instructions






5.979-754.0 (02/26)


## KÄRCHER

# RVF 7 COMFORT QUICKSTART GUIDE



## Buttons station

-  **On/Off** Press for start
-  **Switch mode** Press to switch cleaning mode of robot:  
dry cleaning or wet & dry cleaning
-  **Self-cleaning** Press to activate self cleaning of robot



## Lights station

- Station standby** All lights off
- Device charging** LED stripe: green breathing
- Robot cleaning** LED stripe: white
- Self cleaning activated** LED stripe: blue breathing (wet & dry mode)  
yellow breathing (dry mode)
- Error** LED stripe: red blinking  
LED tanks: red (depending on tank error)

100,5 mm

104 mm

104 mm

100,5 mm

409 mm

# INSIDE

## Install device

- Consider correct positioning
- Attach side brushes
- Place the robot in Multifunctional station
- Download Kärcher Indoor Robots App
- Add robot
- Scan QR code
- Press On/Off and Home to connect to WLAN
- Network configuration
- Device is now ready for use
- Start mapping
- Map configuration  
For the best experience with your robot.  
Duration approx. 5 minutes  
LATER START

Follow the configuration steps in the App
- Device is now ready for use

## Start cleaning

- Detach fresh water tank
- Fill fresh water container with water and detergent (3 caps = 20 ml)
- Add foam stop (optional, if needed) (1 small bottle = 30ml)
- Attach fresh water tank
- Select cleaning mode: dry cleaning (off) or wet & dry cleaning (blue)
- Start cleaning

## Cleaning of station



- Detach dirt water container
- Empty and clean dirt water container
- Attach dirt water container
- Detach fresh water tank
- Refill fresh water container with water and detergent (3 caps = 20 ml)
- Attach fresh water tank

## Changing of filter bag (optional, when needed)

- Detach filter bag
- Dispose filter bag
- Attach new filter bag

## Cleaning of robot



- Detach dirt water tank
- Clean dirt water tank
- Dry sensors
- Attach dirt water tank
- Remove roller unit
- Detach roller
- Wash roller in washing machine
- Attach roller unit
- Clean roller unit
- Wipe all sensors
- Wipe LIDAR sensor

210 mm

100,5 mm

104 mm

104 mm

100,5 mm

409 mm